

Finding Devices

Category : SMC / Installation / General

Q: [How can I find out the IP address of NSC3615?](#)

SMC provides the "Scan" button to scan those IPCam devices of the same LAN segment. Make sure your SMC PC is pre-configured with the same LAN segment of the target IPCam.

Use an Ethernet hub / switch or crossover cable to find the IPCam device. The scan function can not broadcast the packet across router device.

If you do not know how to pre-configure your SMC PC, try to make IPCam device to factory default and make sure you SMC is of the same LAN segment of IPCam device.



Scan

Hostname	IP
88660520010	172.16.4.39
3712	172.16.4.120
5103732701D01L0	172.16.4.85
3712	172.16.4.18

Selected

No.	Hostname	IP
-----	----------	----



SCAN

MODIFY

ADD

APPLY

BACK